

ZeroFlush Urinal Standard Insert Daily Cleaning Instructions

Before commencing cleaning of a ZeroFlush urinal with the standard insert using the BioPur enzyme and odour barrier oil system:

- Be aware of the current Safety Data Sheet (SDS)
- Always wear surgical or rubber gloves
- Check for visible evidence of any maintenance requirements



Step 1

Inspect the urinal for any solid debris including pubic hairs and remove from the bowl of the urinal and around the drain outlets.



Step 2

Wipe clean the inside and outside of the urinal with a soft cloth or paper towel then apply Aquatemp Spray & Go urinal cleaner and deodouriser all over the inside and outside of the urinal.



Step 3

Finally, clean the urinal with a microfibre cloth where you have applied Aquatemp Spray & Go. This will remove any stubborn stains, as well as lime scale, calcium, uric salts, and other organics, leaving the urinal sparkling clean.